

Page 5, line 18, change "computer)" to --computer--.

Page 6, line 20, change "troubles" to --trouble--.

Page 8, line 20, after "such" insert --a--.

Page 14, line 13, after "or" delete "a".

Page 21, line 1, delete "an".

Page 22, line 10, delete "a".

Page 26, line 10, change "toward" to --to--.

Page 27, line 23, after "modes such as" delete "the".

Page 27, line 27, change "remaining capacity" to --capacity remaining--.

Page 28, line 1, change "remaining capacity" to --capacity remaining--.

Page 29, line 12, delete "is".

Page 30, line 5, change "TXON/OFF" to --TX ON/OFF--.

Page 30, line 15, after "showing" insert --the--.

Page 36, line 19, change "remaining capacity" to --capacity remaining--.

Page 37, line 20, change "remaining capacity" to --capacity remaining--.

Page 38, lines 6 and 18, change "remaining capacity" to --capacity remaining--.

Page 39, lines 3 and 13, change "remaining capacity" to --capacity remaining--.

Page 40, lines 2, 4, and 9, change "remaining capacity" to --capacity remaining--.

Page 45, line 26, change "46" to --PC--.

Page 49, lines 8 and 19, change "remaining capacity" to --capacity remaining--.